



<i>XLR F - XLR F</i>	① REF: 1854 XLR H - XLR H
<i>XLR F - RCA F</i>	② REF: 1848 XLR H - RCA H
<i>XLR F - RCA M</i>	③ REF: 1855 XLR H - RCA M
<i>XLR F - JACK MONO</i>	④ REF: 1850 XLR H - JACK MONO
<i>XLR F - JACK STEREO</i>	⑤ REF: 1856 XLR H - JACK STEREO
<i>XLR F - JACK FEMALE MONO</i>	⑥ REF: 1853 XLR H - JACK HEMBRA MONO
<i>XLR M - XLR M</i>	⑦ REF: 1852 XLR M - XLR M
<i>XLR M - RCA F</i>	⑧ REF: 1849 XLR M - RCA H
<i>XLR M - RCA M</i>	⑨ REF: 1851 XLR M - RCA M
<i>XLR M - JACK MONO</i>	⑩ REF: 1857 XLR M - JACK MONO
<i>XLR M - JACK STEREO</i>	⑪ REF: 1894 XLR M - JACK STEREO

<i>Mic adaptor TALL XLR-F</i>	① REF: 2729 Adaptador para micro alto XLR-H
<i>Mic adaptor SHORT XLR-F</i>	② REF: 2727 Adaptador para micro bajo XLR-H
<i>Mic adaptor tall XLR-H and lateral cable out XLR-M. With switch.</i>	③ REF: 2730 Adaptador para micro alto XLR-H y salida cable lateral XLR-M. Con interruptor.
<i>Mic adaptor</i>	④ REF: 2728 Adaptador micro

<i>XLR 3 M - 2 XLR 3 M - 1 XLR 3 F</i>	① REF: PT18157 XLR 3 M - 2 XLR 3 M - 1 XLR 3 H
<i>JACK 6,3 ST - JACK 6,3 M + JACK 6,3 M (insert)</i>	② REF: PT18158 JACK 6,3 ST - JACK 6,3 M + JACK 6,3 M (insert)
<i>JACK 6,3 ST - 4 JACK 6,3 ST</i>	③ REF: PT18159 JACK 6,3 ST - 4 JACK 6,3 ST
<i>XLR 5 F - 2 XLR 5 M - 1 XLR 5 M</i>	④ REF: PT18160 XLR 5 H - 2 XLR 5 M - 1 XLR 5 M
<i>XLR 5 F - 2 XLR 5 F - 1 XLR 5 M</i>	⑤ REF: PT16161 XLR 5 H - 2 XLR 5 H - 1 XLR 5 M
<i>JACK 6,3 ST - 2 JACK 3,5 ST - 1 JACK 6,3 ST - RCA L + RCA R - 1 BANTAM</i>	⑥ REF: PT18162 JACK 6,3 ST - 2 JACK 3,5 ST - 1 JACK 6,3 ST - RCA L + RCA R - 1 BANTAM
<i>1 BANTAM - 6 BANTAM</i>	⑦ REF: PT18163 1 BANTAM - 6 BANTAM